TRS
(Stereo plug)

SIQUE Usually ground

:Right-hand channel for stereo signals, negative phase for balanced mono signal sources :Right-hand channel for signals, signals,

Left - hand channel for stereo signals, positive phase for balanced mono signals signal line for unbalanced mono signals.