



EJECT • TV VIDEO



• TV/ VIDEO

COUNTER/ REMAIN

• AUDIO MONITOR




• DISPLAY

CLEAR



• ENTER




SP/EP

• VOL

• CH




INPUT SELECT



• REC

SEARCH



SLOW

X2

REPLAY



MENU

PAUSE

COMMERCIAL SKIP



REW



FF



STOP



VIDEO